

## INSTALLATION INSTRUCTION



**DIMENSION: 90X90X210CM**

### Honored users :

Thanks for using our products . For your safety, please read this instruction manual carefully before the installation and using of this shower cabin.

**WARNING :** We strongly recommend that this shower cabin be installed by experienced professionals other than untrained personnel .

### Content :

1 Preparations -----	1
2 Installation Process -----	2
3 Cleaning& Maintenance -----	7
4 Transportation&Storage -----	7

## 1. Preparations

1.1 Install two water supply holes (one for cold and another for hot), one drainage hole (diameter  $\geq 5\text{cm}$ ) according to the location of the drainage

1.2 Check the products and spare parts inside the package  
all the parts are packed in three cartons .



1.3 Tear off the protective cover on the tray and the back panel.

**Parts list :**

Positions	Name	Quantity
<u>A1</u>	Back Panel	1 pc
<u>A2</u>	Tray	2pcs
	Ceiling cover	2pcs
	alloy arc	2pcs
	Foot massage	1pc
<u>A3</u>	Sliding glass	2pcs
	Fixed glass	2pcs
	Vertical alloy profile	2pcs
	Waterproof strip	2pcs
	Accessories	1 bag
	Rubber strip	2pcs
	Magnetic seal	2pcs

**Accessories parts**



**A**

A. 5\*25 (14pcs)



**B**

B.4\*25 (8pcs)



**C**

C. 4\*12 (smaller cap) (12pcs)



**D**

D. 4\*12 (12pcs)



**clip (4pcs)**



**roller and rubber stop(8pcs each)**

## 2. Installation process



pic 1



pic 2



pic 3



pic 4

1. Connect the alloy arcs to the vertical alloy profiles. With screw : 4\*25 as in pic 1

2. the alloy frame finishes as pic 2

3/4. Cover the fixed glass panel ( the plane one ) with the soft rubber strip then embed it

firmly into the cut of the alloy profile . As shown in pic 3 and 4 .



pic 5



pic 6



pic 7



pic 8

5. Push the clip hard against the glass and drill the positioning hole. As in pic 5

6 . fix it with screw :4\*12(smaller cap) , as in pic 6

7 . Assemble the rollers to the sliding glass panels (the ones with radius) , make sure that

the rollers are not firmly fastened ,otherwise the rollers can not get into the orbit. As in pic 7

8. Place the sliding glass panels into the orbit . As in pic8



pic 9



pic 10



pic 11



pic 12

9 . Press the knob on the bottom roller , the orbit will let in the roller . As shown in pic 9

10.Cover the sliding glass panels with magnetic door seals. As in pic 10

11. Cover the other ends of sliding doors with waterproof strip. As in pic 11

12. Assemble the handles onto the sliding glass door . As in pic 12



pic 13



pic 14



pic 15



pic 16

13.Fix the plastic rubber stops to both top and bottom alloy arcs to make sure

that the sliding glass would stop at a proper place . with screw :4\*12(smaller cap) as in pic 13

14 . The glass door finishes as pic 14

15. Take the back panel from the package as in pic 15

16. Assemble the tap to the faucet as pic 16



pic 17



18

pic



pic 19



pic 20

17. Installation of the handheld shower head. As in pic 17

18 Connect the hose to the water inlet , as in pic 18

19. Place the handheld showerhead onto the brace preinstalled . As in pic 19

20 Installation of the foot massage. As in pic 20



pic 21



pic 22



pic 23



pic 24

21.Take the tray from the package, as pic 21

22. Put the finished back panel and glass door onto the tray. As pic 22

23. Drill holes on the alloy profiles according to the holes predrilled on the back panel .

note: holes should not be drilled through. As in pic 23

24 Drill through holes on the tray according the holes pre drilled on the panel. As in pic 24



pic 25



pic 26



pic 27



pic 28

25. Use screws : 4\*12 to fix the alloy profiles and the back panel. As in pic 25

26. Use screws : 5\*25 to fix the back panel to the tray. As in pic 26

27 . Partially finished as pic 27

28 . Assembling of the ceiling roof . As in pic 28



pic 29



pic 30



pic 31



pic 32

29. Drill holes on the ceiling according to back panel . Then use screw 5\*25 fixing them . As pic 29

30. Find the plastic corner joints , 3pcs required . As pic 30

31. Corner joint should be applied when connecting the hose to inlets of the handheld

shower head , ceiling shower head and foot massage. As shown in Pic 31.

32. fix the voltage transformer on the top of ceiling With screw 4\*12, as pic 32



pic 33



pic 34



pic 35

33. find the interfaces on the back of the controlling panel . As pic 33

34. Connect the interfaces correctly as the labels instruct . Seen pic 34

35. Installation completed as pic 35

### **3.Cleaning&Maintaining**

3.1 You can use common liquid detergent and soft cotton cloth to clean the shower cabin .  
if something sticky left in the shower cabin, try some gasoline .

3.2 Do not clean the shower cabin with rough tools or detergent with chemical solvents

3.3 Do not hammer and carve the shower cabin with blunt or sharp object .

### **4.Transportation & Storage**

4.1 keep the right side up ,do not pile up the products. Keep the shower cabin away from  
organic solvent , such as formic acid and formaldehyde

4.2 Handle the shower cabin with care, avoid heavy pressure, mechanical shock and violent  
movement

4.3 If the shower cabin is not being used for a long time , please keep the environment dry  
ventilated and no corrosive gas .