

## INSTALLATION INSTRUCTION



**DIMENSION: 90X90X195CM**

**Honored users :**

Thanks for using our products . For your safety, please read this instruction manual carefully before the installation and using of this show cabin.

**WARNING :** We strongly recommend that this shower cabin be installed by experienced professionals other than untrained personnel .

**Content :**

1 Preparations ----- 2  
2 Installation Process ----- 2  
3 Cleaning& Maintenance ----- 4  
4 Transportation&Storage ----- 6

**1. Preparations**

1.1 Install two water supply holes (one for cold and another for hot), one drainage hole (diameter  $\geq 5\text{cm}$ ) accroding the location of the drainage

1.2 Check the products and spare parts inside the package  
all the parts are packed in two cartons .



1.3 Tear off the protective cover on the tray and the back panel.

Parts list :

Positions	Name	Quantity
<u>A1</u>	Tray	1pcs
	alloy arc	2pcs
<u>A2</u>	Sliding glass Panels	2pcs
	Fixed glass Panels	2pcs
	Vertical alloy profiles	2pcs
	Waterproof strip	2pcs
	Accessories	1 bag
	Soft Rubber strip	2pcs
	Magnetic seal	2pcs

Accessories parts



A

A.4\*25 (8pcs)



B

B. 4\*12 (12pcs)



C

C. 4\*25 (6pcs) wall mounting



clip (4pcs)



rubber stop(8pcs)



Roller (8pcs)

## 2. Installation process



pic 1



pic 2



pic 3



pic 4

1. Connect the alloy arcs to the vertical alloy profiles . With screw : 4\*25 as in pic 1

2. the alloy frame finishes as pic 2

3/4. Cover the fixed glass panel ( the plane one ) with the soft rubber strip then embed it firmly into the cut of the alloy profile . As shown in pic 3 and 4 .



pic 5



pic 6



pic 7



pic 8

5. Push the clip hard against the glass and drill the positioning hole. As in pic 5

6 . Fix it with screw :4\*12, as in pic 6

7 . Assemble the rollers to the sliding glass panels (the ones with radius) , make sure that the rollers are not firmly fastened ,otherwise the rollers can not get into the orbit. As in pic 7

8. Place the sliding glass panels into the orbit . As in pic8



pic 9



pic 10



pic 11



pic 12

9 . Press the knob on the bottom roller , the orbit will let in the roller . As shown in pic 9

10.Cover the sliding glass panels with magnetic door seals. As in pic 10

11. Cover the other ends of sliding doors with waterproof strip. As in pic 11

12. Assemble the handles onto the sliding glass door . As in pic 12



pic 13



pic 14



pic 15



pic 16

13.Fix the plastic rubber stops to both top and bottom alloy arcs to make sure that the sliding glass would stop at a proper place . with screw :4\*12, as in pic 13

14 . The glass door finishes as pic 14

15. Put the door frame on the tray and drill hose through holes predrilled on the alloy profiles .

16. Insert the plastic cap into the holes, fix the profile to the wall with screw 4\*25.



**pic 17**

**17. Installation finishes as Pic 17**

### **3.Cleaning&Maintaining**

**3.1 You can use common liquid detergent and soft cotton cloth to clean the shower cabin .**

**if something sticky left in the shower cabin, try some gasoline .**

**3.2 Do not clean the shower cabin with rough tools or detergent with chemical solvents**

**3.3 Do not hammer and carve the shower cabin with blunt or sharp object .**

### **4.Transportation & Storage**

**4.1 keep the right side up ,do not pile up the products. Keep the shower cabin away from organic solvent , such as formic acid and formaldehyde**

**4.2 Handle the shower cabin with care, avoid heavy pressure, mechanical shock and violent movement**

**4.3 If the shower cabin is not being used for a long time , please keep the environment dry ventilated and no corrosive gas .**