

INSTALLATION INSTRUCTION



DIMENSION: 70X90X210CM

Honored users :

Thanks for using our products . For your safety, please read this instruction manual carefully before the installation and using of this shower cabin.

WARNING : We strongly recommend that this shower cabin be installed by experienced professionals other than untrained personnel .

Content :

1 Preparations ----- 1

2 Installation Process ----- 2

3 Cleaning& Maintenance ----- 7

4 Transportation&Storage ----- 7

1. Preparations

1.1 Install two water supply holes (one for cold and another for hot),

one drainage hole (diameter $\geq 5\text{cm}$) according to the location of the drainage

1.2 Check the products and spare parts inside the package

all the parts are packed in three cartons .



1.3 Tear off the protective cover on the tray and the back panel.

Parts list :

Positions	Name	Quantity
<u>A1</u>	Back Panel	2 pcs
<u>A2</u>	Fixed glass	2pcs
	Sliding glass	2pcs
	Vertical alloy profile	2pcs
	Waterproof strip	2pcs
	Accessories	1 bag
	Rubber strip	2pcs
	Mangetic seal	2pcs
	Alloy frame	4pcs
	<u>A3</u>	Tray
Ceiling cover		2pcs
Foot massage		1pc

Screw parts



A

A. 5*25



B

B.4*25



C

C. 4*12(smaller cap)



D

D. 4*12



E

E. 4*10

2. Installation process



pic 1



pic 2



pic 3



pic 4

1. Connect the alloy frame to the vertical alloy profile . With screw : 4*25

2. Insert the corner joint into the alloy frame

3. Drill holes

4. Fix the corner joint with screws : 4*10 ,

then carefully select another piece of alloy profile that matches it .

NOTE : top alloy frame (in width) should go with top alloy(in length)



pic 5



pic 6



pic 7



pic 8

5/6. Cover the fixed glass with the soft rubber strip then embed it firmly into

cut of the alloy profile . As shown in pic 5 and 6

7. put the clip against the fixed glass ,then drill hole , fix it with screw :4*12(smaller cap)

8. Fix the plastic rubber to the predrilled holes on top and bottom alloy profiles to make sure

that the sliding glass would stop at a proper place . With with screw :4*12(smaller cap)



pic 9



pic 10



pic 11



pic 12

9. Assemble the roller to the holes that are predrilled on the sliding glass , make sure that the roller is not firmly fastened ,otherwise the it can not get into the orbit in the arc .

As pic 9

10. Place the double rollers into the upper orbit , then push the nob on the bottom roller , the orbit will let in the wheel . As shown in pic 10

11. Twist the screw as in pic 11 to make adjustment to the height of the sliding glass .

12. Assemble the handle to the predrilled hole ,as in pic 12



pic 13



pic 14



pic 15



pic 16

13. Cover the sliding glass door with the magnetic door seal , as in pic 13

14. Cover the other end the sliding glass with the waterproof strip ,as in pic 14

15. Install the foot massage .

16. Put together the two back panels , make sure not gap left .



pic 17



pic 18



pic 19



pic 20

17. Drill 5 positioning holes through this two panels

drilling position is by user's own definition . As in pic 17

18. fix the two panels by screws : 5*25 as in pic 18

19. Positioning hole on the vertical profile should be drilled in the same way

screw:4*12 are applied

Positioning holes on both tray and ceiling cover according to the holes predrilled on

the panels ,for the panel with seat, screw 5*25 should be applied .

20. Fix the Voltage Transformer to the inside brim of the ceiling cover , fix it with screw



pic 21



pic 22



pic 23



pic 24

21. Loose all the wirings behind the controlling panel as pic 21

22. Lead all the wiring through the holes predrilled on the ceiling cover as pic 22

23. Connect the interfaces properly as the labels instruct . Seen in pic 23

24. Installation completed as pic 24

STEAM OPTION

If the system goes with steam option , please note the below :



pic 25



pic 26



pic 27



pic 28

25.The steam system consists of the main control box and the steam generator . Pic 25&26

27.Retreat the screw on the steam generator, as in pic 27

28.Fix the steel sheet on to the steam generator as in pic 28



pic 29



pic 30



pic 31



pic 32

29. connect the drainage to the outlet of the the steam generator . As in pic 29

30. The steam generator **MUST** be installed upwards. Screw 4*12 are applied .

31.Commutator is applied when it comes to pipeline connection as in pic 31

Make sure that every joint is firmly fastened .

32. All the electric interfaces should be connected correctly as the labels instruct .

NOTICE :

A . Rise the Antenna line up certain height otherwise it would not be able to

pick up the signals .

B .The earth line on the steam generator must be well grounded .

C .Interfaces must be connected as the labels instruct, please take the electrical

layout in the Operation Manual as reference .

D. If the sliding glass door can not stop at a proper position, please repositioning the rubber stop .

3.Cleaning&Maintaining

3.1 You can use common liquid detergent and soft cotton cloth to clean the shower cabin .

if something sticky left in the shower cabin, try some gasoline .

3.2 Do not clean the shower cabin with rough tools or detergent with chemical solvents

3.3 Do not hammer and carve the shower cabin with blunt or sharp object .

4.Transportation & Storage

4.1 keep the right side up ,do not pile up the products. Keep the shower cabin away from

organic solvent , such as formic acid and formaldehyde

4.2 Handle the shower cabin with care, avoid heavy pressure, mechanical shock and violent

movement

4.3 If the shower cabin is not being used for a long time , please keep the environment dry

ventilated and no corrosive gas .